



Computer Methods (a division of Physio Systems, Inc.)
1660 West Linne Road Suite H
Tracy, CA 95377
(510) 824 0252



PHOENIXKONNECT

INSTALLATION GUIDE





Contents

Introduction	3
System Requirements	3
PK Downloads	3
File Staging Area	4
Order of Operations	4
Driver Installation for SDVXI Hardware	5
Step 1: NIVXI 16.0 Driver.....	5
Step 2: Enable NIVisaTulip in NIMAX	7
Step 3: Install Agilent Visa (Agilent Connection Expert)	8
Step 4: Install the EX2500A Controller Drivers (32B and 64B)	9
Step 5: Verify Connectivity to the EX2500a Controller	10
Step 6: Configure Agilent Connection Expert.....	11
Step 7: Verify that NIVISA Has Access to Resources (optional)	13
Legacy ImpaxSD Installations	15
Step 1: NIVISA 16.0 Runtime.....	15
MECALC Mainframe Installation	17
Single mainframe connected directly to PC or laptop	17
Multiple mainframes connected directly to PC.....	18
Single mainframe connected to a local network with high-speed video camera .	19
PhoenixKconnect Installation	20
Step 1: Download the Latest PhoenixKconnect Release	20
Step 2: Run the PhoenixKconnect Setup File	20





Introduction

PhoenixKconnect (PK) is a software application that supports data acquisition from SDVXI-only, MECALC-only or combined hardware configurations. The purpose of this document is to describe the process for installation of the PK application and associated drivers to support this broad range of hardware.

System Requirements

PK targets the Windows®10 (or higher) operating system. The recommended configuration of the host computer (PC or laptop) is:

- Intel i7 Processor
- 17.3-inch Monitor (Touch optional)
- 16GB DDR4 RAM
- 1TB SSD Hard Drive
- Gigabit Ethernet Adapter with RJ45 connection
- Windows®10 / 11 Professional

PK Downloads

Application and driver installation files are available for download at:
<https://www.phoenixkconnect.com/downloads.aspx>.

MECALC systems connect to the computer via wired Ethernet. SDVXI chasses connect to the computer using one or combination of these controllers:

- USB
- EX2500a (Ethernet)

The table below details the files available on the download page and the configurations they support:

Installer File	MECALC	SDVXI + EX2500	SDVXI + USB
PhoenixKconnect Installer (latest version)	✓	✓	✓
MECALC QServer Firmware (latest version)	✓		
NIVXI 16.0		✓	✓
NIVISA 16.0 Runtime (<i>only needed to update existing NIVXI 16.0 installations</i>)		✓	✓
Agilent Connection Expert		✓	
EX2500A VXI Controller Driver 64B		✓	
EX2500A VXI Controller Driver 32B		✓	

Table 1: PK Download Files





File Staging Area

The driver and installation files downloaded from the PK website should be staged in a protected folder on the local hard drive. This is useful for diagnostic and troubleshooting purposes. The best location for this folder depends on the user's environment. It simply needs to be somewhere that automated "cleanup" tools will not remove. Example locations might be:

- **C:\Users\Public\Documents\PK_DO_NOT_DELETE** (for compliance with Windows security)
- **C:\PK_DO_NOT_DELETE** (if user or public profiles are managed remotely or on a network)

Order of Operations

It is important that installers be applied in the following order:





1. If using SDVXI Hardware with either VXI-USB-2 or EX2500a
 - a. NIVXI 16.0 (includes VXI-USB-2 controller support)
2. If using an EX2500a ethernet Controller
 - a. Agilent Connection Expert
 - b. EX2500A VXI Controller Driver 32B
 - c. EX2500A VXI Controller Driver 64B
3. PhoenixKconnect



Driver Installation for SDVXI Hardware

Step 1: NIVXI 16.0 Driver







Download and run the **NIVXI1600.EXE** setup file. After file extraction, select "Install NI-VXI for Windows. Advance through the screens as shown below accepting the defaults (except where indicated):




Uncheck the "Search" Checkbox

PhoenixConnect Installation Guide







Restart the computer




Decline the NI Updates


Step 2: Enable NIVisaTulip in NIMAX

This step is only needed to install the EX2500a ethernet controller. If there are only USB controllers present in SLOT 0 of the chassis, skip this step.

Run National Instrument's **NIMAX – Measurement and Automation Explorer** application. Configure the settings shown below:



Go to **Tools > NI-VISA > VISA Options**



Click **Passports**, Enable **NIVisaTulip.dll** and **Save**






Close the application



Step 3: Install Agilent Visa (Agilent Connection Expert)


This step is only needed to install the EX2500a ethernet controller. If there are only USB controllers present in SLOT 0 of the chassis, skip this step.

Download the file from the **Agilent Visa** link on the PK downloads page. Run the "IOLibSuite_16_3_16603.exe" installer file "**As Administrator**" (right-click on the EXE file and choose "Run as Administrator").




Important: Must be installed as **Secondary VISA
Make sure NIVXI1600 is installed first**







Click **Ok** to move past this screen



Step 4: Install the EX2500A Controller Drivers (32B and 64B)

This step is only needed to install the EX2500a ethernet controller. If there are only USB controllers present in SLOT 0 of the chassis, skip this step.

Download the file "EX2500A_32B_R2p5p0.zip". Extract the contents of the zip file to a temporary location. Open the folder "EX2500A_32B_R2p5p0" and run **setup.exe "As Administrator"** (right-click on the EXE file and choose "Run as Administrator")



If prompted, install the required .NET framework





Download the file "EX2500A_64B_R2p5p0.zip". Extract the contents of the zip file to a temporary location. Open the folder "EX2500A_64B_R2p5p0" and run **setup.exe "As Administrator"** (right-click on the EXE file and choose "Run as Administrator"). Follow the same steps as shown for the 32-bit driver installation.

Step 5: Verify Connectivity to the EX2500a Controller

This step is only needed to install the EX2500a ethernet controller. If there are only USB controllers present in SLOT 0 of the chassis, skip this step.

Make sure the VXI chassis (is/are) powered up.

Before the *Agilent Connection Expert* can be configured, it is important to verify that the EX2500a controller has acquired an IP address on the PC's network. For performance and troubleshooting, it is recommended that the EX2500a be connected to an isolated network. For multiple DAS system configurations (several controllers or combined EX2500a and MECALC mainframes), using a Gigabit switch is advisable. There are two general scenarios:

1. If the network supports DHCP (dynamic host control protocol), the controller will automatically acquire an IP address from the network.
2. When no DHCP server is detected, the host PC will auto-assign an IP address. (PC must be powered up first). The EX2500a will auto-detect the PC's address and select a non-conflicting address in the same subnet as the host to establish communications. Alternatively, static IP addresses can be assigned to the PC's adapter and the EX2500a controller. The organization's IT department may be needed to assist with these configurations and is outside the scope of this document. For questions or help, please contact support@computer-methods.com.

To verify that the EX2500a controller has acquired an IP address, open a Windows command prompt (Windows key + R, type *cmd* in the Run command box and press Enter). In the command window, type "arp -a". This command lists the MAC addresses and IPs for all devices seen on the PC's subnet.

The first three sets of two hexadecimal numbers in a MAC Address identify the card manufacturer. The manufacturer of the EX2500a is VXI Logic and their MAC address prefix is "00:0D:3F". See the snapshot below – the EX2500a controller on this example network has an IP address of "10.0.0.175". Keep this IP address in mind for the next step.



```
C:\WINDOWS\system32\cmd.exe
Microsoft Windows [Version 10.0.19045.4529]
(c) Microsoft Corporation. All rights reserved.

C:\Users\PK-SDVXI>arp -a


Interface: 10.0.0.143 --- 0x6
Internet Address      Physical Address      Type
10.0.0.1              f0-79-59-e9-25-cc    dynamic
10.0.0.2              04-42-1a-ef-45-08    dynamic
10.0.0.159            98-fa-9b-23-eb-4a    dynamic
10.0.0.175            00-0d-3f-01-78-cd    dynamic
10.0.0.255            ff-ff-ff-ff-ff-ff    static
169.254.120.205       00-0d-3f-01-78-cd    dynamic
224.0.0.22            01-00-5e-00-00-16    static
224.0.0.251           01-00-5e-00-00-fb    static
224.0.0.252           01-00-5e-00-00-fc    static
239.255.255.250       01-00-5e-7f-ff-fa    static
255.255.255.255       ff-ff-ff-ff-ff-ff    static


C:\Users\PK-SDVXI>
```

Step 6: Configure Agilent Connection Expert


This step is only needed to install the EX2500a ethernet controller. If there are only USB controllers present in SLOT 0 of the chassis, skip this step.

Launch the Agilent Connection Expert application. Under **System Tasks**, click the link to *Add an Interface*. Highlight the "VXI Technology LXI-VXI Slot 0 Interface" and click Add.






*Click the button to Search Local Network
For multiple controllers, assign a unique
"Logical Unit" number to each controller*



*Select the IP address of the controller and click OK
Test the connection and click OK
Repeat this process for all EX2500a controllers*



Click Refresh All
The controller and VXI cards will be enumerated
REBOOT THE PC

Step 7: Verify that NIVISA Has Access to Resources (optional)

Ensure the PC has been restarted after Step 6 above.

Launch the NI MAX application. Click *Refresh* and expand the Devices and Interfaces node. All SDVXI cards in chassis with EX2500 controllers should be visible in the tree.





The screenshot shows the National Instruments Measurement & Automation Explorer (MAX) interface. The main window is titled "My System - Measurement & Automation Explorer". The left sidebar shows a tree view with "My System" expanded, containing "Devices and Interfaces", "Network Devices", "Miscellaneous VISA Resources", "Software", and "Remote Systems". The "Devices and Interfaces" section is highlighted.

The main content area is divided into two sections: "System Settings" and "System Resources".

System Settings

Hostname	DESKTOP-GNT5800
DNS Name	DESKTOP-GNT5800
Vendor	Micro-Star International Co., Ltd.
Model	Katana GF76 12UE
Serial Number	K2202N0204161
Firmware Version	E17L3IMS.10F
Hardware Revision	REV:1.0
Operating System	Microsoft Windows 10 Pro
System Start Time	6/22/2024 10:48 PM
Description	
System Configuration Web Access	Local Only

System Resources

Total Physical Memory	31.7 GB
Free Physical Memory	27.0 GB
Total Virtual Memory	36.5 GB
Free Virtual Memory	31.6 GB
Primary Disk Capacity	1.84 TB
Primary Disk Free Space	1.78 TB
CPU Model	12th Gen Intel(R) Core(TM) i7-12700H
CPU Total Load	6% 0% 0% 0% 12% 6% 6% 6% 0% 6% 1
CPU Interrupt Load	0% 0% 0% 0% 0% 0% 0% 0% 0% 0% 0

The right sidebar contains a "National Instruments Measurement & Automation Explorer" section with a "Back" button and a "Hide Help" button. Below this is a "What do you want to do?" section with several links: "Manage my devices and interfaces", "Manage my installed National Instruments software", "Manage virtual channels or tasks for my devices", "Create scales for my virtual instruments", "Configure my IVI instrument drivers", and "Import/export my device configuration file". A "Note" section follows, stating that some categories are device-specific and that the IVI category appears only if IVI is installed. At the bottom, there is a link to the National Instruments Technical Support website.







Legacy ImpaxSD Installations

Step 1: NIVISA 16.0 Runtime

This step is only needed for existing (legacy) installations of ImpaxSD




The version of the National Instruments NIVXI 16.0 driver provided with ImpaxSD from Spectral Dynamics installed an older version of the NIVISA runtime library. The NIVXI 16.0 driver itself is ok to use with PhoenixKconnect. However, the NIVISA library must be updated.

Download and run the **setup.exe** installer in the **NIVISA1600runtime.zip** compressed folder.



*Accept the default feature settings.
Make sure the "Search for updates" checkbox is **unchecked**.*








MECALC Mainframe Installation

MECALC mainframes communicate with the PC over Ethernet. Each mainframe supports a browser-based interface that configures the mainframe's network settings. There are several possible network topologies – the appropriate configuration depends on the number of mainframes and the site's IT requirements. This guide will present three common scenarios:

1. Single mainframe connected directly to PC
2. Multiple mainframes connected to a PC
3. Single mainframe connected to a local network with a high-speed video camera

Single mainframe connected directly to PC or laptop




By default, the network adapters in MECALC mainframes obtain an IP from the client's [DHCP](#) server. In the diagram above, there is no DHCP server available. Consequently, the mainframe's ethernet adapter will auto-assign its IP address ([APIPA](#)) in the range of 169.254.1.0 through 169.254.254.255 with a subnet mask of 255.255.0.0.

If the ethernet adapter of the PC is configured to "Obtain an IP address automatically", the adapter will also auto-assign an IP address in the same subnet. PhoenixKconnect can scan the local network and locate the mainframe.



Multiple mainframes connected directly to PC




Multiple mainframes are connected to MECALC's SP45 PTP switch (installed in any one of the mainframes). The SP-45 supports the [PTP](#) network protocol. Each mainframe is configured for PTP, ensuring that clocks on all modules are synchronized for alignment of channel data. The PC connects to one of the open ports of the SP-45 switch.

The mainframes will auto-assign their IP addresses ([APIPA](#)) in the range of 169.254.1.0 through 169.254.254.255 with a subnet mask of 255.255.0.0. If the ethernet adapter of the PC is configured to "Obtain an IP address automatically", the adapter will also auto-assign an IP address in the same subnet. PhoenixKconnect can scan the LAN and detect the mainframes.



Single mainframe connected to a local network with high-speed video camera



Tools and software provided by a camera manufacturer may require a LAN with a specific IP address range. In the diagram above, all ethernet adapters are configured with a static IP address and appropriate subnet mask. Additional ethernet-based devices (such as an LXI-VXI EX2500a controller) can be added to the LAN if assigned a static IP in the subnet range.




PhoenixKonnnect Installation

Step 1: Download the Latest PhoenixKonnnect Release

Download the **PhoenixKonnnect** installer from the [Download](#) page of the PK website. The installer found on this page is the current production release. This link will be periodically updated as releases are made available.

Step 2: Run the PhoenixKonnnect Setup File






By default, the PK installer will maintain compliance with Windows® best practices by placing all PK configuration and data files in the “Users\Public” folder. The *ImpaxSD Legacy* option is intended for current ImpaxSD users that have their own tools for accessing and post-processing of data files. When the legacy option is enabled, the installer will:


- Create a *Phoenix* folder on the root of the C:\ drive
- Maintain all configuration and data files in the C:*Phoenix* location
- Store data files using legacy ImpaxSD naming conventions
 - Data files stored in a “flat” file directory structure for each test
 - Data file extensions reference run numbers



Computer Methods (a division of Physio Systems, Inc.)
1660 West Linne Road Suite H
Tracy, CA 95377
(510) 824 0252



*If the **Modify Setup** dialog appears, it means this component has already been installed. Just click **Close**.*



***Congratulations!**
PhoenixKonnnect is installed and ready to use.
A shortcut to the application will appear on the desktop.*

PhoenixKonnnect Installation Guide





Computer Methods (a division of Physio Systems, Inc.)
1660 West Linne Road Suite H
Tracy, CA 95377
(510) 824 0252

There are tutorials available on the website to get started with the PK application. Go to <https://phoenixkonnnect.com>, click on the **Downloads** menu and navigate to **Tutorials and Guides**.

